5. General Diagnostic Table

A: INSPECTION

Symptom	Possible cause	Corrective action
	Parking brake pedal is misadjusted.	Adjust.
Droke drog	Parking brake cable does not move.	Correct or replace.
Brake drag	Parking brake shoe clearance is maladjusted.	Adjust.
	Return spring is faulty.	Replace.
Noise from brake	Return spring is faulty.	Replace.
Noise iroill brake	Brake shoe spring fault	Replace.

POWER ASSISTED SYSTEM (POWER STEERING)

PS

		Page
1.	General Description	2
2.	Steering Wheel	13
	Universal Joint	
4.	Tilt Steering Column	16
5.	Steering Gearbox	18
6.	Pipe Assembly	39
7.	Oil Pump	43
8.	Reservoir Tank	51
9.	Power Steering Fluid	52
	General Diagnostic Table	